


# Seitenpanel

## Seitenpanel Eingänge

1. OPS PC Eingang
2. WIFI Antennen
3. USB-A 3.0 Eingang
4. USB-C Eingang
5. Touch 1 (USB)
6. HDMI 1 - ARC Port
7. Touch 2 (USB)
8. HDMI 2 - Port
9. Touch 3 (USB)
10. Display Port (DP)



Revision #1

Created 7 August 2024 08:16:18 by Sandi Andrijevic

Updated 31 October 2024 10:21:17 by Sandi Andrijevic